

BOTH ENDS OF THE CABLE HAVE TO GO TO EITHER THE THERMOSTAT OR THE CONTACTOR, OR OTHER POWER SOURCE.


SPLICES MUST BE TOTALLY ENCASED IN SCREED.

MAINTAIN 1/2 OF RECOMMENDED CABLE SPACING BETWEEN THE CABLE AND THE WALLS OR OTHER PERMANENT STRUCTURE.

CABLE SPACING REFERS TO THE DISTANCE BETWEEN THE PARALLEL RUNS OF CABLE.

DIAMETER OF RETURN BEND MUST NEVER BE LESS THAN 2 INCHES.

MAINTAIN RECOMMENDED SPACING BETWEEN CABLE ON THE HOME RUN.




Orbit Manufacturing


CABLE PLACEMENT I

Drawn By: jsa


ORB 20022 Rev. 0



Orbit Manufacturing
CABLE PLACEMENT II
Drawn By: jsa ORB 20020 Rev. 0



Orbit Manufacturing	
CABLE PLACMENT III	
Drawn By: jsa	ORB 20024 Rev. 0



Orbit Manufacturing

CABLE PLACEMENT EXAMPLE IV

Drawn By: jsa

ORB 20025 Rev. 0